

2D

**Wireless Barcode Scanner
Manual Guide**



Table of contents

Working Mode.....	1
Upload mode	2
Power and Standby Setup.....	3
Interface setup.....	3
Language Setup	4
Capital & Lowercase Setup.....	5
Trigger Mode	5
End Mark	5
Buzzer Setup	6
Reverse Code Reading.....	6
Duplicate Barcode Upload Setup.....	7
Invoice Function.....	7
Barcode Setting	8
CODE128	8
EAN 8.....	8
EAN 13.....	9
UPC-E0	9
UPC-A	10
Interleaved 2 of 5	12
MATRIX 25.....	12
CODE 39.....	12
CODE 32.....	13
CODABAR.....	14
CODE 93.....	15
CODE 11.....	15
ISBN.....	15
ISSN.....	15
INDUSTRIAL25	16
STANDARD25.....	16
MSI_Plessey.....	16
QR.....	16
PDF417	17
Aztec	17
DataMatrix	17
MicroPDF417.....	17
MicroQR	17
Add Prefix.....	18
Add Suffix	18
Delete Characters.....	19
Appendix 1: Parameter Code	20
Appendix 2:ASCII.....	22

■ Scan barcode to setup scanner



Restore Defaults
(decoding function)



Restore Defaults
(wireless function)

Note: Scan "Restore Defaults(decoding function)" and "Restore Defaults (wireless function)" in order to restore the scanner to the factory status.

Working Mode

■ 2.4G Match Operation:

2.4G receiver has been matched by default, plug in the receiver and scan the "2.4G" setting code to use. If you need to match it again, first unplug the receiver, then re-plug the receiver into the computer, scan the "2.4G Mode" setting code within 20 seconds, the match is successful.



2.4G Mode

■ Bluetooth Match Operation:

Scan the "Bluetooth HID Mode" setting code, the blue indicator flashes quickly, turn on the device's Bluetooth option, click "Scanner xxx", the blue indicator becomes steady on, the match is successful.



Bluetooth HID Mode (Only to Bluetooth products)

■ Bluetooth BLE Mode:

Scan the "Bluetooth BLE Mode" setting code. (Developers use, general users scan carefully)



Bluetooth BLE Mode (Only to Bluetooth products)

To show and hide iOS keyboard (Only to Bluetooth products)



iOS keyboard Show/Hide



Double click show/hide iOS
keyboard--ON/OFF

Upload mode

■ Three Upload Mode: Instant Upload Mode, Storage Mode, Non-losing Mode

► Instant upload mode

Instant upload data to your computer



Instant Upload Mode

(1)Upload successfully: the buzzer rang"Di".

(2)Upload failed: the buzzer rang"Di-di-di".

► Storage Mode

In storage mode, the barcode will be stored in scanner's own memory and will not come up on your computer instantly. The barcode comes up on your computer only when you scan the settings code "upload data" within the wireless transmission range.



Storage Mode

Note: During use, if data cannot be uploaded, please confirm whether it is set to storage mode.






► Non-losing Mode

The barcode will be uploaded to the receiver in real-time when the scanner is in wireless transmission range. When the scanner is out of the wireless transmission range, the data will be stored in scanner's own memory . After scanner is reaching the wireless transmission range,scan "Upload Data" setting barcode,the lost data which are stored will be uploaded to the computer automatically.











Non-losing Mode

Note: Before using the non-losing mode, it is better to scan the code "Clear Data" to clear the data of scanner.

 Show Total Storage	 Upload Data
 High Upload Speed(*default)	 Low Upload Speed
 Clear Data	



Power and Standby Setup

 Battery Reserve	 Standby Immediately
 Set the time for automatic shutdown	 2 Minutes-Default
 10 Minutes	 20 Minutes
 8 hours	 Never Standby

► Set the time for automatic shutdown

For example, if you want to set the power off time to be 20 Minutes. First scan "Set the time for automatic shutdown ", then scan "20 Minutes".

Interface setup

 USB-HID*Default	 USB virtual COM
Note: In USB virtual COM mode, the scanner needs to work with driver and serial software. Please contact us if you need to set it to USB virtual COM mode,we will send you the driver and the serial software.	

Language Setup



UNITED STATES*



JAPAN



FRANCE



GERMANY



SPAIN



SPAIN(MEXCIO)



ITALY



PORTUGAL(BRAZIL)



TURKEY



PORTUGAL



CZECH REPUBLIC



NORWAY



RUSSIA



FINLAND(SWEDEN)

Capital & Lowercase Setup



All Capital



All Lowercase



Swap Capital/Lowercase



No Swap*

Trigger Mode



Continuous Mode



Auto-Sensing Mode

End Mark



None



CR



LF+CR



TAB



LF



ETX

Buzzer Setup



Volume-ON*



Volume-OFF



Volume-ON*



Volume-OFF

Reverse Code Reading

Turning on this setting will affect the scanning speed, please turn it on while you need to use



ON



OFF

Duplicate Barcode Upload Setup



Duplicate Detection-ON
(Auto-Sensing Mode)



Duplicate Detection-OFF*
(Auto-Sensing Mode)



Delay forever
(Auto-Sensing Mode)



Delay 3s
(Auto-Sensing Mode)



Duplicate Detection-ON
(Continue Scan Mode)



Duplicate Detection-OFF*
(Continue Scan Mode)



Delay forever
(Continue Scan Mode)



Delay 3s
(Continue Scan Mode)

Invoice Function



Invoice Function-ON



Invoice Function-OFF

Barcode Setting

CODE128



OFF



ON

EAN 8



OFF



ON



Check Digit-OFF



Check Digit-ON



2 Extra Code-OFF



2 Extra Code-NO



5 Extra Code-OFF



5 Extra Code-ON

EAN 13



OFF



ON



Check Digit-OFF



Check Digit-ON



2 Extra Code-OFF



2 Extra Code-NO



5 Extra Code-OFF



5 Extra Code-ON

UPC-E0



OFF



ON



Check Digit-OFF



Check Digit-ON



2 Extra Code-OFF



2 Extra Code-NO



5 Extra Code-OFF



5 Extra Code-ON



System Digit-OFF



System Digit-ON

UPC-A



OFF



ON



Check Digit-OFF



Check Digit-ON



2 Extra Code-OFF



2 Extra Code-ON



5 Extra Code-OFF



5 Extra Code-ON



System Digit-OFF



System Digit-ON



UPCA to EAN13-OFF



UPCA to EAN13-ON

Interleaved 2 of 5



OFF



ON



Check Digit-OFF



Check Digit-ON

MATRIX 25



OFF



ON



Check Digit-OFF



Check Digit-ON

CODE 39



OFF



ON



Check Digit-OFF



Check Digit-ON



Start&End Digit-OFF



Start&End Digit-ON



Full ASCII-OFF



Full ASCII-ON

CODE 32



OFF



ON



Prefix-OFF



Prefix-ON



Check Digit-OFF



Check Digit-ON

CODABAR



OFF



ON



Start&End Digit-OFF



StartABCD/End DigitABCD-ON



StartABCD/End DigitTN*E-ON



Start abcd/End Digit abcd-ON



Start abcd/End Digit tn*e-ON

CODE 93



OFF



ON

CODE 11



OFF



ON

ISBN



OFF



ON

ISSN



OFF



ON

INDUSTRIAL25



OFF



ON

STANDARD25



OFF



ON

MSI_Plessey



OFF



ON

QR



OFF



ON

PDF417



OFF



ON

Aztec



OFF



ON

DataMatrix



OFF



ON

MicroPDF417



OFF



ON

MicroQR



OFF



ON

Add Prefix



Display Prefix-OFF



Display Prefix-ON



Add Prefix

E.g. The bar code content is "123456789", add X and Y before the bar code(Check ASCII Barcode Table, X=58, Y=59), "XY123456789" will be shown.

Please scan the following code in order:

"Display Prefix-ON">"Add Prefix">Parameter Code"5","8","5","9">"Save settings"

Add Suffix



Display Suffix-OFF



Display Suffix-ON



Add Suffix

E.g. The bar code content is "123456789", add X and Y after the bar code(Check ASCII Barcode Table, X=58, Y=59), "123456789XY" will be shown.

Please scan the following code in order:

"Display Suffix-ON">"Add Suffix">Parameter Code"5","8","5","9">"Save settings"

Delete Characters



Delete Characters-OFF



Delete Characters-ON



Before Barcode



After Barcode

E.g. The bar code content is "123456789", if you want to set the scanner to delete the number 1, "23456789" will be shown.

Please scan the following code in order:

"Delete Characters-ON">"Before Barcode">"Parameter Code "0">"Parameter Code "1">"Save settings"

Appendix 1: Parameter Code



0



1



2



3



4



5



6



7



8



9



A



B



C



D



E



F



Save settings

Appendix 2:ASCII

Hex	Dec	Description	Hex	Dec	Description	Hex	Dec	Description
00	0	NUL	2B	43	+	56	86	V
01	1	SOH	2C	44	,	57	87	W
02	2	STX	2D	45	—	58	88	X
03	3	ETX	2E	46	。	59	89	Y
04	4	EOT	2F	47	/	5A	90	Z
05	5	ENQ	30	48	0	5B	91	[
06	6	ACK	31	49	1	5C	92	\
07	7	BEL	32	50	2	5D	93]
08	8	BS(Backspace)	33	51	3	5E	94	^
09	9	HT(Tab)	34	52	4	5F	95	_
0A	10	LF(CTRL J)	35	53	5	60	96	`
0B	11	VT(CTRLK)	36	54	6	61	97	a
0C	12	FF(CTRL L)	37	55	7	62	98	b
0D	13	CR(Enter)	38	56	8	63	99	c
0E	14	SO(CTRL N)	39	57	9	64	100	d
0F	15	SI(CTRL O)	3A	58	:	65	101	e
10	16	DLE(CTRL P)	3B	59	;	66	102	f
11	17	DC1(CTRL Q)	3C	60	<	67	103	g
12	18	DC2(CTRL R)	3D	61	=	68	104	h
13	19	DC3(CTRL S)	3E	62	>	69	105	i
14	20	DC4(CTRL T)	3F	63	?	6A	106	j
15	21	NAK(CTRL U)	40	64	@	6B	107	k
16	22	SYN(CTRL V)	41	65	A	6C	108	l
17	23	ETB(CTRL W)	42	66	B	6D	109	m
18	24	CAN(CTRL X)	43	67	C	6E	110	n
19	25	EM(CTRL Y)	44	68	D	6F	111	o
1A	26	SUB(CTRL Z)	45	69	E	70	112	p
1B	27	ESC(ESC)	46	70	F	71	113	q
1C	28	FS(CTRL \)	47	71	G	72	114	r
1D	29	GS(CTRL])	48	72	H	73	115	s
1E	30	RS(CTRL ^)	49	73	I	74	116	t
1F	31	US(CTRL _)	4A	74	J	75	117	u
20	32	(space)	4B	75	K	76	118	v
21	33	!	4C	76	L	77	119	w
22	34	"	4D	77	M	78	120	x
23	35	#	4E	78	N	79	121	y
24	36	\$	4F	79	O	7A	122	z
25	37	%	50	80	P	7B	123	{
26	38	&	51	81	Q	7C	124	
27	39	'	52	82	R	7D	125	}
28	40	(53	83	S	7E	126	~
29	41)	54	84	T	7F	127	DEL
2A	42	*	55	85	U			